

Connect to the purple wire of the interface and/or unit's powercable

Cut off and put RCA plug on in order to use with Avic-F950BT

Connect to the car side

Put in to the back of the Avic unit where the microphone should go

