

CA-R-MAN.001



STEERING WHEEL REMOTE CONTROL

Lenkradfernbedienung / Adaptateur commande au volant / Stuurafstandsbediening



Knöpfe abziehen und Schrauben ausdrehen
pull off buttons and remove screws

MAN


TGX, TGS, TGA, TGM
(nur mit / only with 2DIN Radio)

Tools / Werkzeug / Outils / Gereedschap





Screwdriver - torx
Schraubenzieher-Torx
tournevis - torx

Pink Wire (Rose) – Speed Pulse
(Impulsion de Vitesse)



- | | |
|---------------------|---------------------------|
| A1 = Not connected | Non relié |
| A2 = Not connected | Non relié |
| A3 = Not connected | Non relié |
| A4 = +12 Volt | +12 Volt |
| A5 = Antenna Remote | Extérieur d'antenne |
| A6 = Illumination | Illumination |
| A7 = Ignition | Ignition |
| A8 = Ground | Après contact/Masse/Maron |
-





1	Lautstärke +	volume +	
2	Lautstärke -	volume -	
3	Titel + oder Sendersuchlauf +	titel + or seek +	
4	Titel - oder Sendersuchlauf -	titel - or seek -	