

Steering wheel control interface installation kit for:


# FCA125 DUAL CAN

Model: Jeep Renegade  
Jeep Compass  
Fiat 500X  
Fiat Tipo

Year: 2021>

Kit content: Antenna adapter  
Radio adapter  
SWC CANBUS interface  
Wiring harness


Customer code: CD-SCA-UAR.002AE



## INSTALLATION MANUAL

All installation work must be performed by a qualified professional installer only.  
The manufacturer / dealer is not liable for any kind of incidental or indirect damages.  
05/2023 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.

# Wiring:



## ATTENTION!

In order to prevent ESD damage, the WHEEL REMOTE JACK must be connected before plugging in the connectors on car side.

- 1- To CAR CONNECTOR
- 2- PHANTOM POWER:  
2a- JACK DIN - To RADIO ANTENNA CONNECTOR  
2b- MALE FAKRA - To CAR ANTENNA CONNECTOR
- 3- SWC - To WIRED REMOTE SOCKET (NOTE: do not connect to microphone socket)
- 4- RADIO CONNECTOR
- 5- UART CONNECTOR
- 6- MALE RCA PLUG - To RADIO CAMERA INPUT
- 7- Black wire GND
- 8- Red wire UNDERKEY

<b>Output voltage</b>
V battery –0.2 V at 0.5 A
V battery – 1.0 V at 2.0 A

V battery	
Min.	Max.
9 Vdc	16 Vdc

# Configuration:

## - Steering button configuration for Jeep Renegade :

An example of a possible steering button configuration:



The steering wheel buttons perform the following functions (if supported by the radio):

- 1- Source
- 2- Seek down
- 3- Seek up
- 4- Incoming call
- 5- Voice
- 6- Reject call
- 7- Volume +
- 8- Volume –
- 9- Mute

# Radio configuration

The available settings are (if the related optional is equipped by the car):

\*To check the latest, updated compatible features, please scan the QR code below.

## A. Display

- Language

## B. Doors & Looks

- Auto unlock on exit
- Lock autoclose

## C. Lights

- Ambient light intensity
- Automatic high beam
- Cornering
- Courtesy light time
- Flash light with lock
- Headlight sensitivity

## D. Mirror and wipers

- Rain sensor

## E. Safety

- Anticollision warning
- Automatic parking brake
- Brake maintenance
- Follow me
- Lane assist
- Lane assist strength
- Park assist
- Parking sensors
- Passive entry
- Rear park assist vol.
- Side sense

## F. Time and date

**PLEASE NOTE:** The time is not shown on the MFD


## G. Units



- Consumption
- Distance
- Speed

**PLEASE NOTE:** The speed unit is updated after an ignition cycle



- Below is an example of accessing the interface settings menu:





**PLEASE NOTE:**

To configure the radio, select the configuration for your vehicle in the 'Vehicle Settings' submenu. Once the configuration has been selected, press "Save".

The radio is now ready to operate with the selected configuration.

<b>Configuration</b>	<b>Brand</b>	<b>Model</b>
RENEGADE	Fiat	500X VP2
RENEGADE	Fiat	Tipo VP2
RENEGADE	Jeep	Renegade VP2
RENEGADE	Jeep	Compass VP2

All installation work must be performed by a qualified professional installer only.  
The manufacturer / dealer is not liable for any kind of incidental or indirect damages.  
05/2023 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.