

CHANGE HISTORY for AVIC-F550BT

Do NOT use the default Micro SD memory card provided with your unit as this card contains the map data. (After this card is formatted, it is not possible anymore to use it for navigation, even when the data is copied again on the card)

Ver 1.27 (23 October, 2014 Update)

- ✓ Fixed an issue that certain settings might reset to default when starting the unit at low temperature.